




SENTRY Screens

Package Contents:

1 x Mesh Screen
1 x Roll of Velcro

1 x Pack of Pushpins
2 x Tie Backs



Visit www.SentryScreens.com/installation-tips for installation videos & tips.

Installation Instructions:

- Clean your installation surface** - Using either hot soapy water or an isopropyl (rubbing alcohol), clean the surface where the Velcro will be stuck to the door frame. Allow time to dry.
- Position the screen** - With a helper, pick up the screen (from the top) and hold it up to the door frame. Mark the position of the screen with a pen, pencil, or marker.
 - Make sure** that the bottom of the screen hangs about 0.5cm – 1cm above the ground. If the screen drags on the ground, the bottom magnets won't automatically close.
 - The **top-middle** of the screen should be positioned about 1cm – 2cm higher than the top corners. This is so that the natural tendency of the magnets is to attract rather than pull apart.
 - Make sure that you don't pull the screen so tight that the magnets are being pulled apart.
- Attach the Velcro**
 - Cut the Velcro to the same width & height of the screen.
 - Carefully remove the white backing tape from the Velcro. Stick it to the door frame where you marked it in step #2. We recommend the top first, then the sides. **Press and hold each section for at least 30 seconds to allow the glue to set.**
- Attach the screen door**
 - Attach the soft-side Velcro of the screen door to the Velcro on the door frame.
 - Make sure that the sides are not too tight that they are pulling the magnets apart.
 - Make sure that the top middle is 1cm – 2cm higher than the top corners.
 - Press the provided pushpins evenly around the screen edge, through the screen edge and Velcro. This isn't a necessity but will ensure that the screen stays securely in place. **Especially the top.**
 - Caution: the pins will leave small holes in your door frame.
- Attach the tie-backs** – (if desired) Slide the tie-backs in between the hard and soft Velcro, about mid-height of the screen door. This will allow you to keep each screen panel open.

For more instructions, pictures, and videos on how to correctly install the screen door, check out www.SentryScreens.com

Free Lifetime Warranty Upgrade

To qualify for the **Lifetime Warranty Upgrade**, you must register at:

www.SentryScreens.com/register-sentry/

Is Your Magnetic Screen Too Long or Too Wide?

Save yourself the time and cost of returning the screen! You can simply adjust it to be shorter and/or narrower to fit your door exactly.



Visit our customer portal where you'll get access to instructions and videos for your magnetic screen.

If you need help with installation, or have issues with your screen, contact our customer support directly!

www.BTPremiumProducts.com/customer

Check out our other products/brands at:



Web: www.BTPremiumProducts.com

Email: support@btpremiumproducts.com